## INTRODUCING THE NEW **ACS A-CLIP®**

- **EASIER TO INSTALL**
- ADJUSTABLE FROM ZERO TO 1" IN PRECISE 1/8" INCREMENTS
- PRE-DRILLED HOLES SAVE TIME AND ENERGY

## HOW TO USE THE ADJUSTING FEATURE:

- 1) Install the base piece using attachment screws selected from the ACS Thermal Clip Structural Design Guide.
- 2) Slide the adjustment piece over the base.
- 3) Line the holes up with the desired increment. There will be two holes for each number:

$$0 = 0$$
" (Min)

$$1 = 1/8$$
"

$$2 = 1/4$$
"


$$3 = 3/8$$
"

$$4 = 1/2$$
"


$$6 = 3/4$$
"

$$8 = 1" (Max)$$


4) Use the #12 self-tapping stainless steel screws provided to lock the adjustment in place. The ACS A-Clip® must be secured with 2 screws.



Screws set in the #3 position for a 3/8" adjustment.



Screws set in the #4 position for a 1/2" adjustment.



Screws set in the #8 position for a 1" or maximum adjustment.



